



Installing Key Blockers on your X-keys

After removing the key you will also need to ***remove the key plunger***.

This is to avoid having the Key Blockers from popping up.



Using needle nose pliers, grip the stem of the Key Plunger and pull straight upward.



Insert the Key Blocker and press into place.



The Key Blocker should stay flat without the key plunger pushing up on it.

You can always reinsert the key plungers and add keys back to your layout.