



# Freestanding Dual Vertical







#### IMPORTANT INFORMATION

- ! Please ensure this product is installed as per these installation instructions.
- ! Each VFS Display Head supports a maximum weight as per above weight range specification.
- ! Each 750mm (29.5") Upright Pole supports a maximum of two VFS Display Heads.
- ! This product supports VESA mounting hole configurations: 75x75mm and 100x100mm.
- ! The manufacturer accepts no responsibility for incorrect installation.
- ! Curved monitors, deep devices (such as all-in-one PCs), VESA mounted accessories (such as mini PC brackets and mounts), and offset VESA locations exert additional leverage that can exceed the capacity of the mount even though the monitor weight may be within the stated range. Please contact Atdec if you would like further information.


#### 1. Attach Upright Pole to Base




## 2. Attach VFS Display Heads to the Pole (Ensure the cable slot faces towards the rear)




#### **3.** Attach the VESA Plate to your monitor (Repeat steps 3 to 6 for each monitor)




## 4. Attach your Display to the VFS Display Head




**4.2** Press and hold the Release Buttons. Gently push bottom of VESA Plate into Display Head Mount. Release Buttons to lock in place.






Screwdriver


## 5. Adjust the Height of the VFS Display Head




**5.2** Slide the VFS Display Head to desired position.




**5.3** If necessary, adjust the tension between the Display Head and the Pole using the 5mm Allen Key supplied.



**5.4** Close the lever to lock the VFS Display Head in place.



### 6. Adjust the ball joint tension



## 7. Cable Management

Connect cables to your Displays, routing them down to the rear of the poles.

Push the cables into the slots, using either the Cable Balls or Cable Clips to secure them to the pole as shown.

Note: Ensure enough slack is left in cables to allow for movement. When the slot in each pole cannot be used, use the supplied Cable Clips to secure the cables.

