

User Manual 17" / 19" High Brightness LCD 1000 cd/m²



Designed and manufactured by Austin Hughes

Legal Information

First English printing, July 2023

Information in this document has been carefully checked for accuracy; however, no guarantee is given to the correctness of the contents. The information in this document is subject to change without notice. We are not liable for any injury or loss that results from the use of this equipment.

Safety Instructions

Please read all of these instructions carefully before you use the device. Save this manual for future reference.

- Unplug equipment before cleaning. Don't use liquid or spray detergent; use a moist cloth.
- Keep equipment away from excessive humidity and heat. Preferably, keep it in an air-conditioned environment with temperatures not exceeding 40° Celsius (104° Fahrenheit).
- When installing, place the equipment on a sturdy, level surface to prevent it from accidentally falling and causing damage to other equipment or injury to persons nearby.
- When the equipment is in an open position, do not cover, block or in any way obstruct the gap between it and the power supply. Proper air convection is necessary to keep it from overheating.
- Arrange the equipment's power cord in such a way that others won't trip or fall over it.
- If you are using a power cord that didn't ship with the equipment, ensure that it is rated for the voltage and current labeled on the equipment's electrical ratings label. The voltage rating on the cord should be higher than the one listed on the equipment's ratings label.
- Observe all precautions and warnings attached to the equipment.
- If you don't intend on using the equipment for a long time, disconnect it from the power outlet to prevent being damaged by transient over-voltage.
- Keep all liquids away from the equipment to minimize the risk of accidental spillage. Liquid spilled on to the power supply or on other hardware may cause damage, fire or electrical shock.
- Only qualified service personnel should open the chassis. Opening it yourself could damage the equipment and invalidate its warranty.
- If any part of the equipment becomes damaged or stops functioning, have it checked by qualified service personnel.

What the warranty does not cover

- Any product, on which the serial number has been defaced, modified or removed.
- Damage, deterioration or malfunction resulting from:
 - Accident, misuse, neglect, fire, water, lightning, or other acts of nature, unauthorized product modification, or failure to follow instructions supplied with the product.
 - $\hfill\square$ Repair or attempted repair by anyone not authorized by us.
 - □ Any damage of the product due to shipment.
 - □ Removal or installation of the product.
 - $\hfill\square$ Causes external to the product, such as electric power fluctuation or failure.
 - $\hfill\square$ Use of supplies or parts not meeting our specifications.
 - \Box Normal wear and tear.
 - $\hfill\square$ Any other causes which does not relate to a product defect.
- Removal, installation, and set-up service charges.

Regulatory Notices Federal Communications Commission (FCC)

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

Any changes or modifications made to this equipment may void the user's authority to operate this equipment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Re-position or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Contents

< Part. 1 > RP-H117 / RP-H119

ackage Content	P.1
tructure Diagram & Dimension	P.1
stallation	P.3
t	tructure Diagram & Dimension

< Part. 2 > Specifications / OSD

2.1	Product Specifications	P.4
2.2	On-screen Display Operation (OSD)	P.7

< Part. 3 > Options

3G / HD / SD-SDI Broadcast-grade input	P.10
Speaker, DVI-D, BNC	P.11
Touchscreen : Projected Capacitive(10-point touch) Resistive / Capacitive(1-point touch)	P.12
DC Power : 12V / 24V / 48V / 125V / 250V	P.14
	Speaker, DVI-D, BNC Touchscreen : Projected Capacitive (10-point touch) Resistive / Capacitive (1-point touch)

Before Installation

- It is very important to mount the equipment in a suitable cabinet or on a stable surface.
- Make sure the place has a good ventilation, is out of direct sunlight, away from sources of excessive dust, dirt, heat, water, moisture and vibration.

Unpacking

The equipment comes with the standard parts shown in package content. Check and make sure they are included and in good condition. If anything is missing, or damaged, contact the supplier immediately.

How To Clean Your LCD Monitor

A Caution :

- To avoid the risk of electric shock, make sure your hands are dry before unplugging your monitor from or plugging your monitor into an electrical outlet.
- When you clean your monitor, do not press down on the LCD screen. Pressing down on the screen can scratch or damage your display. Pressure damage is not covered under warranty.
- Use only cleansers made specifically for cleaning monitors and monitor screens. Cleansers not made to clean monitors and monitor screens can scratch the LCD display or strip off the finish.
- Do not spray any kind of liquid directly onto the screen or case of your monitor. Spraying liquids directly onto the screen or case can cause damage which is not covered under warranty.
- Do not use paper towels or abrasive pads to clean your monitor. Using an abrasive pad or any wood based paper product such as paper towels can scratch your LCD screen.

Cleaning Your Monitor

To clean your LCD safely, please follow these steps :

- ① Disconnect the power cord.
- ② Gently wipe the surface using a clean, dry microfiber cloth. Use as little pressure as possible.

Cleaning Tough Marks and Smudges

To remove tough marks and smudges, please follow these steps :

- ① Disconnect the power cord.
- ② Spray a small amount of non-abrasive cleanser on a microfiber cloth.

Caution : Do not spray or apply any liquids directly onto the monitor. Always apply the solution to your microfiber cloth first, not directly on the parts you are cleaning.

- ③ Gently wipe the surface. Use as little pressure as possible.
- ④ Wait until your monitor is completely dry before plugging it in and powering it up.

< Part 1 > RP-H117 / RP-H119 < 1.1 > Package Content

RP-H117 / H119




RP-H117 or RP-H119 unit X1

- 6ft VGA cable X1
- Power cord X1
- M6 screw, cage nut & cup washer X8


The above package content is only for the pure model (VGA and HDMI only). It varies with options such as DVI-D, AV, audio, touchscreen & DC power.

< 1.2 > Structure Diagram



< 1.3 > Dimension


Front View




Rear View



Side View



Top View




Model	Product Dimension (W x D x H)	Packing Dimension (W x D x H)	Net Weight	Gross Weight
RP-H117 series	441.6 x 500 x 44 mm	588 x 758 x 120 mm	10.5 kg	16.5 kg
	17.4 x 18.9 x 1.73 inch	23.1 x 29.8 x 4.7 inch	23.1 lb	36.3 lb
RP-H119 series	441.6 x 500 x 44 mm	588 x 758 x 120 mm	12.5 kg	18.5 kg
	17.4 x 19.7 x 1.73 inch	23.1 x 29.8 x 4.7 inch	27.5 lb	40.7 lb

The weight is only for the pure models. It varies with accessories & options such as DVI-D, AV, audio, touchscreen & DC power.

UNIT : mm 1mm = 0.03937 inch


< 1.3 > Installation - How to install Installation Slides

RP-H117 / H119






Insert the left and right rear mounting brackets into the display drawer.





- Measure the depth of the front and rear mounting rails.
- Align each rear mounting bracket to a suitable length.





Fix the display drawer into the rack.





After use the drawer

Basically, user can push in the drawer back to park position by releasing the left & right slide lock arrow (as long as the drawer starts moving, he/she can release their finger right away, holding the arrow is not necessary).

< Part 2 > Specifications / OSD

< 2.1 > Product Specifications

LCD Banal		RP-H117	RP-H119
Panel	Panel Size (diagonal)	17-inch TFT color LCD	19-inch TFT color LCD
	Display pixel (dots x lines)	1280 x 1024	1280 x 1024
	Brightness (typ.)	1000	1000
	Contrast Ratio (typ.)	1000:1	1000:1
	Color	16.7 M	16.7 M
	Viewing Angle (L/R/U/D)	85/85/80/80	85/85/80/80
	Response Time (ms)	5	5
	Dot pitch (mm)	0.264	0.294
	Display Area(mm)	337.92H x 270.33V	376.32H x 301.06V
	Surface treatment	Anti-glare	Haze 25%, Hard-coating
	Surface hardness	3H	3H
	Backlight Type	LED	LED
	MTBF(hrs)	50,000	30,000

Video	Digital	HDMI	HDMI 1.4, HDCP 1.4
Connectivity		DVI	DVI-D, TMDS single link
	Analog	VGA	Analog 0.7Vp-p
		Composite (BNC)	NTSC & PAL
		S-Video (4-pin)	NTSC & PAL
	Plug & Play	DVI / VGA	VESA EDID structure 1.3
	Synchronization	VGA	Separate, Composite & SOG

Audio	Audio Input	Connector	3.5mm stereo jack
Connectivity		Impedance / Power level	30kΩ / 750mV
	Audio Output	Connector	3.5mm stereo jack
		Resistance / Power level	30kΩ / 2.8V
	Speaker	Dual Stereo Speaker	2W x 2

* When the audio output is connected, speaker output is OFF

Power	Power Supply	Range	Auto-sensing 100 to 240VAC,
			50 / 60Hz
	Power Consumption	Screen ON	
			7) Max. 30W
		(RP-H11	9)Max. 39W
		Power saving mode	Max. 2W
		Power button OFF	Max. 1W

Compliance	EMC	FCC & CE
	Safety	CE / LVD & UKCA
	Environmental	RoHS3 & REACH / WEEE

RP-H117 / H119

Environmental	Operating	Temperature	0 to 55°C degree
Conditions		Humidity	10~90%, non-condensing
		Altitude	16,000 ft
	Storage / Non-operating	Temperature	-20 to 60°C degree
		Humidity	5~90%, non-condensing
		Altitude	40,000 ft
		Shock	10G acceleration (11ms duration)
		Vibration	10~300Hz 0.5G RMS random

Physical Specification		RP-H117	RP-H119
	Product (W x D x H)	441.6 x 500 x 44 mm	441.6 x 500 x 44 mm
		17.4 x 18.9 x 1.73 inch	17.4 x 19.7 x 1.73 inch
	Packing(W x D x H)	588 x 758 x 120 mm	588 x 758 x 120 mm
		23.1 x 29.8 x 4.7 inch	23.1 x 29.8 x 4.7 inch
	Net Weight	10.5 kg / 23.1 lb	12.5 kg / 27.5 lb
	Gross Weight	16.5 kg / 36.3 lb	18.5 kg / 40.7 lb

* All dimensions stated are subject to change if options are selected / integrated to base model part codes

Applicable	DVI-D / VGA Input	PC Signal	1280 x 1024 x 60 / 75Hz
Format			1280 x 960 x 60Hz
			1280 x 768 x 60 / 75Hz
			1152 x 864 x 75Hz
			1024 x 768 x 60 / 70 / 75Hz
			848 x 480 x 60Hz
			800 x 600 x 60 / 72 / 75Hz
			720 x 400 x 70Hz
			640 x 480 x 60 / 72 / 75Hz
			640 x 400 x 70Hz
			640 x 350 x 70Hz
	HDMI Input	PC Signal	Same as VGA
		Video Signal	720p : 50 / 60Hz
			480p : 60Hz
			576p : 50Hz
		Audio Signal	2ch Linear PCM (32 / 44.1 / 48 KHz)

Intentionally Left Blank

< 2.2 > On-screen Display Operation (OSD)

Image: Construction of the construc	~	> ⅲ ⊃ ७
Image: Constraint of the constraint		
Image: Display the OSD menu Act as an Enter key to select screen setting options Image: Optimized Screen	Membrane Switch	Function
Image: Second control Image: Second control Image: Second contrel Image: Second contrel <td>Ċ</td> <td>Turn the monitor on or off</td>	Ċ	Turn the monitor on or off
Image: Construction of the displayed control Image: Construction of the displayed control Image: Construction of the displayed control Exit the OSD screen Go back to the previous on-screen sub-menu or main menu Go back to the previous on-screen sub-menu or main menu Remark : All LED touch buttons in WHITE light. The LED of Power Image: touch button will flash continuously when there is no signal input Image: Construction of the left touch buttons will automatically turn off after 10 minutes of idle status (except the Power Image: Construction of the left touch button will flash continuously when there is no signal input		· ·
Go back to the previous on-screen sub-menu or main menu Remark : All LED touch buttons in WHITE light. The LED of Power touch button will flash continuously when there is no signal inpu (1) All the LED touch buttons will automatically turn off after 10 minutes of idle status (except the Po		
The LED of Power (b) touch button will flash continuously when there is no signal inpu (1) All the LED touch buttons will automatically turn off after 10 minutes of idle status (except the Po) D	Go back to the previous on-screen sub-menu or
2 Light up all membrane buttons, please press any button for 1 - 2 seconds (except the Power) All the LED touch buttons will automat	ically turn off after 10 minutes of idle status (except the Power 🖑
)Light up all membrane buttons, please	e press any button for 1 - 2 seconds (except the Power 🕲).
③ Select another video input (only available for models with multiple video input):) Select another video input (only availa	ble for models with multiple video input) :
(a) Press the button \supset to call up the on-screen video mode on top right corner.	(a) Press the button $ \heartsuit $ to call up th	e on-screen video mode on top right corner.
(b) Use up/down arrow $~~\bigwedge~~ igvee ~~$ to the select the video input	(b) Use up/down arrow 🕅 to th	ne select the video input
(c)Press the button	(c)Press the button 誯 to confirm t	he selection

< 2.2 > On-screen Display Operation (OSD)


1 Picture

Brightness : Adjust the screen brightness

Contrast	: Adjust the difference between the image background
	(black level) and the foreground (white level)
Black level	: Adjust background black level of the screen

- Full Screen / 4:3 / 5:4 / Pixel to Pixel

Eco : Screen in power saving mode



	F	POSITION	DP 384	0x2160@60.0I	Ηz
PICTURE	PICTURE SIZE		FULL	SCREEN	>
	DP VERSION			DP 1.2	>
COLOR					
OSD SET					
RESET					
PIP					
MISC	▲/▼: UP/DOWN	∢/ ▶: −/+		MENU:EX 30STD7011	

3 Color

2

Position

Picture size : Adjust the image size

DP version : Select the DP version

Color temperature	: User / Warm / Cool / 5400k mode and Red / Green / Blue color balance
Sharpness	: Adjust the image from weak to sharp
Hue	: Adjust the screen hue value
Saturation	: Adjust the saturation of the image color
Dynamic Iuminous control	: Control the dynamic brightness

		COLOR	DP 3840x2160@60.0H	z
	COLOR TEMPERATURE		USER	>
←	SHARPNESS		50	>
POSITION	HUE		50	>
	SATURATION		50	>
COLOR	DYNAMIC LUMINOUS C	ONTROL	OFF	>
OSD SET				
RESET				
RESET				
PIP				
MISC	▲/▼: UP/DOWN	∢/ ▶: -/+	MENU:EXI M91KW430STD701L	
misc.				

(4) OSD Set

Language	: Select the language in which the OSD menu is displayed - English
OSD H-Position	: Align the screen image left or right
OSD V-Position	: Align the screen image up or down
OSD time out	: Adjust the screen timeout
OSD transparency	: Adjust the screen transparency
OSD size	: Adjust the screen size - Normal / Small
OSD rotation	: Rotate the screen - 90° / 180° / 270°

	OSE) SET	DP 3840x2160@60.0Hz
	LANGUAGE		
←	OSD H-POSITION		50 >
POSITION	OSD V-POSITION		50 >
	OSD TIME OUT		<u> </u>
COLOR	OSD TRANSPARENCY		0 >
	OSD SIZE		NORMAL >
	OSD ROTATION		OFF >
RESET			
PIP			
MISC	▲/▼: UP/DOWN	∢/ ▶: - /+	MENU:EXIT M91KW430STD701LG

< 2.2 > On-screen Display Operation (OSD)

5 Reset


Reset : Return the adjustment back to factory setting

RP-H117 / H119

		RESET	DP 3840x2160@60.0Hz
	RESET		
COLOR			
OSD SET			
RESET			
PIP			
MISC	▲/ ▼ : UP/DOWN	4 /▶: - /+	MENU:EXIT M91KW430STD701LG

6 PIP (Not Applicable to F17 / MF17)

PIP mode	: Enter into PIP / PBP setting - PIP MODE / PBP 2WIN (Main screen + 1 sub screen) / PBP 3WIN (Main screen + 2 sub screen) / PBP 4WIN (Main screen + 3 sub screen) Select the signal input of each sub screen
PIP size	: Adjust the size of the Sub screen - Small / Medium / Large / Huge
PIP position	: Adjust the position of the Sub screen - Top Left / Top Right / Bottom Left / Bottom Right
Swap	: Swap the input signal of PIP / PBP sub screen



7 MISC


Signal source	e : Select the signal source - DP / HDMI1 / HDMI2
Mute	: Turn off the surrounding sound
Audio in	: Auto / Line in / DP
Volume	: Adjust the volume of sound
Sleep mode	: Set the off time - 10 min / 20 min / 30 min / 50 min / 60 min / 120 min / 240 min

		MISC	DP 3840x2160@60.0Hz	J
	SIGNAL SOURCE		DP >	
←¦ →	MUTE		0FF >	
POSITION	AUDIO IN		AUTO >	
	VOLUME		<u> </u>	
	SLEEP MODE		0FF >	
OSD SET				
RESET				
PIP				
MISC	▲/★: UP/DOWN	∢/ ▶: −/+	MENU : EXIT M91KW430STD701LG	

Options on Reset page

Rotation	: Rotate the image in Full screen or 1:1
	- 90° / 180° / 270°

Picture size : Adjust the image size in Full screen or 1:1




< Part 3 > Options < 3.1 > Options : 3G / HD / SD-SDI input



Austin Hughes' SDI input is an ideal solution for the broadcastgrade video and high resolution CCTV market.

Designed for use with CyberView displays, a SDI input module can support up to 1080p @60Hz resolution without using additional space or power and it comes standard with a 2-year warranty.

* SDI option comes with speakers.



SDI

INPUT	3G-SDI IN	BNC x 1 / 0.8Vp-p (75 ohm)
	3G-SDI OUT	BNC x 1 / Active through, equalized & relocked


Standard Compliance	Video	SMPTE 425M / 274M / 296M / 125M ITU-R BT.656
	Audio	SMPTE 299M / 272M-C

Compatible Video Format	3G-SDI HD-SDI	1080p 1080p 1080i 720p 1080p 1080i	<pre>@60 / 50Hz, 4:2:2 @30 / 25 / 24Hz, 4:4:4 @60 / 50Hz, 4:4:4 @60 / 50Hz, 4:4:4 @30 / 25 / 24Hz, 4:2:2 @60 / 50Hz, 4:2:2</pre>
		720p	@60 / 50Hz, 4:2:2
	SD-SDI	480i	@60Hz, 4:2:2
	ITU-R BT.656	576i	@50Hz, 4:2:2

Compatible Audio Format	3G-SDI	48kHz, 16 / 20 / 24 bit, 2 CH, Synchronized Video
	HD-SDI	48kHz, 16 / 20 / 24 bit, 2 CH, Synchronized Video
	SD-SDI	48kHz, 16 / 20 / 24 bit, 2 CH, Synchronized / Asyn- chronized Video


Max. Transmission Distance 75 ohm coaxial cable	3G-SDI	150m at 2.97Gb/s
	HD-SDI	250m at 1.485Gb/s
	SD-SDI	480m at 270Mb/s

< 3.2 > Options : Speaker, DVI-D, BNC



DVI-D Option

- **DVI-D** (DVI-D, TMDS single link)
- Audio input & output
- Speaker



Chassis extension in depth to 570mm (22.4")

BNC Option

- BNC (S-Video + Composite, BNC)
- Speaker

Power	S-Video	BNC	HDMI VGA CIIIID

Chassis extension in depth to 570mm (22.4")

S-Video + BNC

< 3.3 > Options : Touchscreen & driver



Projected Capacitive 10-pt Touch screen Specification

	RP-H117		
Model	TPC-10 Multi-touch		
Technology	Projected Capacitive		
Touch Point	10		
Input Type	Finger or Capacitive Stylus		
Resolution	4096 x 4096		
Touch Point Accuracy	± 2 mm		
Response Speed	< 5 ms		
Activation Force	< 5 g		
Surface Hardness	6H		
Light Transmission	> 85%		
Haze	3%↓		
Durability	50 million touches		
Top Layer	1.8 mm Glass		
Bottom Layer	0.7 mm Sensor Glass		
Thickness	2.7 ± 0.1 mm		
Connector	USB		
Compatibility	Linux / Android / Windows / Mac		

Resistive 1-pt / Capacitive 1-pt Touch screen Specification

Model	RP-H117	RP-H119	RP-H117
	TRB e-	TCB e-Capacitive	
Technology	5-Wire F	Resistive	Capacitive
Touch Point	Sin	gle	Single
Method	Stylus c	r Finger	Finger
Activation Force	≤ 50g / St	≤ 50g	
Durability	35 millior	300 million touches	
Response Time	15 ms		20 ms
Optical Transmittance	80% ± 3%		93% ±2%
Surface Hardness	3Н		9H
Haze	8% ± 3%		7%
Glass	1.4 ±0.2 mm 3.2 ±0.2 mm		2.8 mm ±10%
Connector	USB	USB Type A	
Compatibility	Windows 7 / XP / Vista, Linux		

■ USB touchscreen package includes 1 x 6ft USB cable, quick reference guideline and CD disc

For detailed information, please refer to the attached CD disc

As the touchscreen unit is not made of toughened glass, please handle it carefully

< 3.3 > Options : Touchscreen & driver

USB Touchscreen

	HDMI
Power	
	VGA
	د(




Chassis extension in depth to 570mm (22.4")

TPC-10 Driver

Connect the USB cable from the USB port on the LCD to a computer. The touch screen supports easy Plug-and-Play operations. There is no need to install additional drivers on the computer.

TRB & TCB Driver



< 3.3 > Options : DC Power



Model	12V	24V	48V	125V	250V
Input rating					
Input voltage:	12-Volt	24-Volt	48-Volt	110-Volt	300-Volt
Input range:	9 ~ 18V	18 ~ 36V	36 ~ 75V	66 ~ 160V	180 ~ 425V
Input current					
- No load	50 mA	50 mA	50 mA	35 mA	10 mA
- Full load	4950 mA	2450 mA	1220 mA	749 mA	600 mA
Output rating					
Output voltage:	12-Volt	12-Volt	12-Volt	12-Volt	12-Volt
Output current:	4.16A	4.16A	4.16A	6.25A	12.5A
Efficiency	84%	85%	85%	91%	86%

DC power

+-	HDMI
စမြာမာစ	VGA e

- ******* For DC power option :
 - (1) If the unit with LCD, earthing may be required 🔒
 - (2) DC option excludes AC power adapter and power cord.
 - (3) Chassis extension in depth to 570mm (22.4")

Intentionally Left Blank

The company reserves the right to modify product specifications without prior notice and assumes no responsibility for any error which may appear in this publication. All brand names, logo and registered trademarks are properties of their respective owners.

Copyright 2023 Austin Hughes Electronics Ltd. All rights reserved.